

PIX-LINK

LV-WR09

KABLOSUZ REPEATER

KURULUM

DÖKÜMANI

Wireless-N Web Server x +

← → Güvenli deę 192.168.1.254 ☆ 🔍 🌐

WIRELESS-N | 300M

Adres satırına 192.168.1.254 ip adresini yazıp "Enter" tuşuna basın.

Gelen arayüz sayfasında "Submit" butonuna basın.

Language English

Submit

Wireless-N Web Server x +

Güvenli değil | 192.168.1.254/index.htm

WIRELESS-N | 300M

Basic Advance Log off

Status
Associated clients : 1

Wizard
WAN Mode : Dynamic IP Address

Wireless
SSID : Wireless-N

WAN Status

WAN Mode	Dynamic IP Address
MAC address	00:E0:20:18:4C:CA
IP address	0.0.0.0
Status	Disconnect
	Release Renew

Internet

MAC address	00:E0:20:18:4C:C9
IP address	192.168.1.254
DHCP	Server

Wireless Status

SSID	Wireless-N
Band	802.11 BGN
Channel	
BSSID	00:E0:20:18:4C:C8

System

Uptime	0 Day, 00:56:37
Firmware version	v28K_MiniRouter.20190211
Build time	2019 Year 2 Month 11 Day

"Wizard" menüsüne basın.

Wireless-N Web Server x +

← → C Güvenli değil | 192.168.1.254/index.htm

WIRELESS-N | 300M

Basic Advance Log off

Status
Associated clients : 1

Wizard
WAN Mode : Dynamic IP Address

Wireless
SSID : Wireless-N

Operation Mode

GateWay

Wireless AP Mode

Wireless Repeater Mode

WISP

Next

"Wireless Repeater Mode" bölümünü seçin ve "Next" butonuna basın.

Wireless-N Web Server x +

Güvenli değil | 192.168.1.254/index.htm

WIRELESS-N | 300M

Basic Advance Log off

Status
Associated clients : 1

Wizard
WAN Mode : Dynamic IP Address

Wireless
SSID : Wireless-N

Wireless Repeater(WDS)

Channel	SSID	Signal	Security type	Select
4	Everest_5V	📶	WPA1PSKWPA2PSK	Select
4	Everest_12V	📶	WPA1PSKWPA2PSK	Select
11	Rampage_Showroom	📶	WPA2PSK	Select
4	S-LINK	📶	WPA1PSKWPA2PSK	Select
11	Segment_Tasarim	📶	WPA2PSK	Select

Back Apply Refresh

Internet alacağınız modemi "Select" butonuna basarak seçin.

Wireless-N Web Server x +
← → Güvenli değil | 192.168.1.254/index.htm

WIRELESS-N | 300M

Basic Advance Log off

Status
Associated clients : 1

Wizard
WAN Mode : Dynamic IP Address

Wireless
SSID : Wireless-N

Wireless Repeater(WDS)

Channel	SSID	Signal	Security type	Select
4	Everest_5V	📶	WPA1PSKWPA2PSK	Select
4	Everest_12V	📶	WPA1PSKWPA2PSK	Select
11	Rampage_Showroom	📶	WPA2PSK	Select
4	S-LINK	📶	WPA1PSKWPA2PSK	Select
11	Segment_Tasarim	📶	WPA2PSK	Select

Connect to: Rampage_Showroom

Extender ssid: Rampage_Showroom_Ext

Security key:

Back Apply Refresh

"Extender ssid" bölümünden "Pix-Link cihazınızın Wifi adını" değiştirebilirsiniz.
"Security key" bölümüne "Seçtiğiniz Ana Modeminizin wifi şifresini" birebir aynı şekilde yazın.
Daha sonra "Apply" butonuna basarak kurulumu tamamlayabilirsiniz.