


s-link

Akıllı 8 in 1 Kumandası Kullanım Kılavuzu






Manuel Arama

Kod Girme ile Çalıştırma

- 1- Arama yapacağınız cihazı çalışır konuma getiriniz,
- 2- Listedeki cihazınızın marka ve cinsine karşılık gelen 4 haneli kodları bulunuz, (ÖRNEK: TV ARÇELİK 1427, vb)
- 3- Kumanda üzerindeki ilgili cihaz tuşuna kumanda ışığı sabit yanana kadar (3 saniye basılı tutunuz, ÖRNEK: TV)
- 4- Kumanda ışığı sabit yandığında basılı tuttuğunuz parmağınızı çekip rakam tuşlarını kullanarak cihaz kodunu giriniz,
- 5- 4 haneli kod doğru girildiğinde kumanda led ışığı söner,
- 6- Kumandanız kullanıma hazırdır, (Girdiğiniz kodu test etmek için kumandanızı cihaza doğrultunuz, Açma/ Kapama tuşuna basınız, Girdiğiniz koddoğru ise cihazınız kapanacaktır)
- 7- Kumandanın cihazı çalıştırmaması durumunda marka ve modele ait diğer Manuel Arama (Kod Girme İle Çalıştırma) kodları deneyin



Tv	
Arçelik	1073, 1095, 1099
Ardem	1208
Artech	1095, 1106
Asa	1006, 1015



Otomatik Arama Çalıştırma Yöntemi

- 1- Arama yapacağınız cihazı çalışır konuma getiriniz ve kumandayı cihaza doğrultunuz,



- 2- Kumanda üzerindeki ilgili cihaz tuşuna (ÖRNEK: TV) Led ışığı sabit yanana kadar basılı tutunuz, (Yaklaşık 3sn,)



- 3- CODE tuşuna bir kere basarak otomatik aramayı başlatın,
(Bu işlem cihaza ait fazla kod olduğundan 15-20 dk,kadar sürebilir)




- 4- Kumanda cihazınıza ait kodu bulduğunda cihazınızı kapatacaktır, Cihazınız kapanır kapanmaz 2 saniye içinde tekrar CODE tuşuna basınız,



- 5- Kumandanız kullanıma hazırdır.

- 6- Kumandanın cihazı çalıştırması durumunda aynı markaya ait diğer kodları deneyiniz.





Öğrenme Özelliğini Kullanma

Bu konumda akıllı kumandanıza başka bir kumandanın özelliklerini yükleyebilirsiniz,

- 1- Kopyalamak istediğiniz kumandanın türüne göre ilgili cihaz tuşuna led ışığı sabit yanana kadar basılı tutun,(ÖRNEK: TV tuşu)
- 3- Led ışığı sabit yandıktan sonra parmağınızı basılı tuttuğunuz tuştan çekiniz,
- 3- Rakam tuşları ile 8888 rakamını gidiğinizde led ışığı yanıp sönmeye başlayacaktır,Artık kumandanız öğrenme konumundadır,
- 4- Akıllı kumandayı ve kopyalanacak kumandayı ledler birbirine karşılıklı gelecek şekilde 1-3 cm mesafede tutunuz,
- 5- İlk olarak hangi tuşu kopyalayacaksınız akıllı kumandanızda aynı tuşa basıp bırakınız,Led ışığı sabit olarak yanacaktır,Kopyalanacak kumanda da arşılık gelen tuşa basıp 1-2 sn bekleyiniz,akıllı kumandanın led ışığı yanıp sönmeye başladığında tuş kopyalama işlemi tamamlanmıştır,
- 6- Aynı işlemi kopyalamak istediğiniz diğer tuşlar için tekrarlayınız,
- 7- Çalışmanızı tamamladıktan sonra öğrenme modundan çıkmak için CODE tuşuna basınız,


NOT: 30 saniye hiçbir tuşa basılmaması durumunda akıllı kumanda otomatik Öğrenme Özelliğini Kullanma olarak öğrenme konumundan çıkar,



Fabrika Ayarlarına Dönme


Bu işlem tüm ayarları silerek akıllı kumandayı orjinal haline getirir,

- 1- Sıfırlamak istediğiniz cihaz tuşuna led ışık sabit yanana kadar basılı tutun,
- 2- Kumanda led ışığı yandıktan sonra parmağınızı tuştan kaldırınız,
- 3- Rakam tuşları ile 1111 rakamını giriniz, Her girilen rakamda led ışığı kısa süreli yanıp sönecektir, Rakam girme işlemi bittiğinde led 2 saniye kadar daha yandıktan sonra tamamen söner ve işlem tamamlanır,



Not: 15 saniye hiçbir tuşa basılmaması durumunda kumanda otomatik olarak bu moddan çıkar,

V2 Universal Remote Control For 8in1



EU


MANUAL SEARCH

(OPERATING BY ENTERING CODE)

- 1- Make the device ready on which you will make searching.
- 2- Find the 4 digit codes from the list which corresponds to your device's brand and type. (E.g: TV Arçelik 1073, etc)
- 3- Keep pushing on the relevant device key on the remote control (about 3 seconds) until the led on the remote control is on continuously. (E.g: TV)
- 4- When the led on the remote control is on continuously, then release the key you were pushing, and enter the device code by using the direction keys.
- 5- The remote control led turns off, when the 4 digit code is entered correctly.
- 6- Now your remote control is ready for use. (For testing the code you entered, point your remote control on the device, push ON/OFF key, if the code that you entered is correct, then the device will turn off)
- 7- In case of the remote control does not activate the device, try the other codes which belong to the brand and type.



Tv	
Arçelik	1073, 1095, 1099
Arçdem	1208
Artech	1095, 1106
Asa	1006, 1015



AUTOMATIC SEARCH OPERATING METHOD

1- Turn on the device on which you will make search, and then point the remote control to the device,



2- Keep pushing the relevant device key (e.g: TV) on the remote control until the led is continuously on, (about 3 seconds)



3- Start automatic searching function by pushing the CODE key once, (this operation might take 15 – 20 seconds since there are many codes belonging to the device)




4- Your device will turn off when the remote control finds the code which is belonging to your device, once your device turns off, push CODE key within 2 seconds,







5- Now your remote control is ready for use,

6- In case of the remote control does not operate your device, repeat the above steps once again.



USING THE LEARNING FUNCTION

In this function, you load another remote control's functions to your universal remote control.

- 1- Keep pushing the relevant device key of the remote control that you want to copy according to its type, until the led is continuously on (E.g: TV key). 
- 3- When the led is continuously on, release your finger from the key. 
- 3- The led will start blinking when you enter 8888 number by the numerical control keys. Now the learning function of the remote control is activated. 
- 4- Hold both the universal remote control and the remote control to be copied on the position that the leds to be faced, at around 1 – 3 cm distance. 
- 5- Firstly, push and release the key that you want to copy on your remote control, the led will be continuously on. Wait 1 – 2 seconds after pushing the corresponding key on the remote control to be copied. When the led of the universal remote control starts blinking, the key copying process will be completed.
- 6- Repeat the same process for all the other keys you want to copy.
- 7- When you are done with the operation, push CODE key for exiting the learning function.


NOTE: In case of not pushing any of the keys for 30 seconds, the universal remote control will exit from the learning function automatically.

RESTORING THE FACTORY SETTINGS

This process makes the universal remote control to the original settings by deleting all the setting up.

- 1- Keep pushing on the device key that you want to initialize, until the led is continuously on.
- 2- Release the key when the led of the remote control is on.
- 3- Enter 1111 number by the numerical control keys. Each time you enter a digit, the led will get blink once shortly. When the code entering process is completed, the led turns on for about 2 seconds and turns off completely, then the process is completed.

Note: In case of not pushing any of the keys for 15 seconds, the remote control will exit from this mode automatically.



TV Markaları
(TV Brands)

TV Kodları
(TV Code)

TV Markaları
(TV Brands)

TV Kodları
(TV Code)

A. R. SYSTEMS 1095,1043, 1044
 ACCENT 1106,1133
 ACTION 1106
 ADMIRAL 1022,1106,1179,1163,1164,
 1191,1193,1342,1343
 AGASHI 1095,1096
 AIDATA 1378, 1377,1380,1383
 AIKO 1045, 1106, 1118
 AIM 1094, 1095, 1096, 1098,
 1044, 1108, 1134, 1182
 AIOSTAY 1106, 1161
 AIWA 1252,1277, 1301
 AKAI 1433,1426,1065,1066,1095,
 1096, 1098, 1002,1019,1045,
 1103, 1106, 1108, 1117, 1118,
 1134, 1138, 1168,1170,1177,
 1158, 1160, 1161, 1162, 1192,
 1195, 1233, 1261, 1264
 AKI 1045
 AKIRA 1094, 1097
 AKURA 1094, 1095, 1106, 1118,
 1133, 1158, 1160
 ALBA 1095,1118,1161,1249
 ALBIRAL 1095,1118, 1161, 1249
 ALHORI 1045
 ALLOGRAN 1045, 1151, 1154, 1255
 ALTUS 1446,1443,1073,1095,1099,
 1137,1146,1161,1185,1188,
 1208,1236,1239,1273,1304,
 316,1350, 1351, 1353, 1354,
 1355, 1324, 1325, 1326,
 1327, 1328, 1329, 1335,
 1336, 1337, 1359
 AMPLIVISION 1044, 1045
 AMSTRAD 1098,1106, 1133, 1134,
 1164, 1245
 ANEX 1095
 ANGLO 1133
 ANITECH 1095,1098,1019,1106,1166,1
 171,1165
 ANSONIC 1095
 ANTECNO 1118
 ARCELIK 1411,1421,1427,1440,1446,
 1443,1073,1095,1099,1137,
 1146,1161,1185,1188,1208,
 1236,1239,1273,1304,1316
 1350, 1351, 1353, 1354,
 1355, 1324, 1325, 1326,
 1327, 1328, 1329, 1335,
 1336, 1337, 1359
 ARDEM 1208
 ART TECH 1095,1106, 1171
 ASA 1006,1015,1016,1020, 1021,

1025, 1179, 1162
 ASBERG 1095,1098,1019,1168
 ASTHON 1095
 ASTON 1216
 ASTRA 1095,1098,1044,1103,1106,1
 161,1213,1282,1283,1294,
 1296,1299
 ASTRO SOUND 1095, 1044, 1166, 1171,
 1161
 ASUKA 1118,1161
 ATAKI 1153,1160, 1161, 1213
 ATLANTIC 1095,1099,1100,1165,1255
 ATORO 1106
 AUDIO STAR 1118,1213
 AUDIOSONIC 1095, 1098, 1099, 1038,
 1043, 1045, 1106, 1118,
 1133, 1166, 1176, 1152,
 1208, 1262, 1316
 AUDIOSTAR 1118,1213
 AUDIOTON 1045,1106,1118,1165,1213
 AURORA 1022, 1045, 1106, 1108
 AUSIND 1012
 AUTOVOX 1095, 1015, 1018, 1019,
 1040, 1045, 1106, 1108,
 1170, 1151, 1154, 1251,
 1255, 1256, 1281, 1343
 AUVISAT 1317
 AWA 1095,1098,1045, 1049, 1106,
 1108, 1170
 AVOL 1442
 AXEN 1405,1080,1363, 1134, 1268,
 1270, 1274, 1279, 1323,
 1334, 1362, 1364
 BAIRD 1170,1182
 BANG 1095, 1098, 1022
 BARCO 1022,1033,1034,1036,1122,
 1123,1125,1161,1182
 BASIC LINE 1095,1098, 1118, 1151,
 1154, 1155, 1213
 BAUR 1094,1095,1097,1098,1002,
 1003,1004,1046,1047,1106,1
 151,1153,1154,1158,1192,
 1307
 BAZIN 1027,1045,1152
 BEKO 1427,1421,1440,1446,1443,
 1411,1073, 1095, 1098,
 1099, 1137, 1146,1152,1161,
 1185,1188,1190,1195,1208,
 1236,1239, 1273,1304,1316,
 1350,1351,1352,1353,1354,
 1355,1324,1325,1326,1327,
 1328,1329, 1335, 1336,
 1337, 1359

TV Markaları (TV Brands)	TV Kodları (TV Code)	TV Markaları (TV Brands)	TV Kodları (TV Code)
BEKOTEKNIK	1099	CONTI	1437,1095, 1098
BEON	1168	CONTIN;EDISON	1026,1035, 1137, 1138,
BIFONIC	1045, 1106	1036, 1115,	1147, 1254
BIGSTON	1106,1108, 1133	1143, 1146,	
BLAUPUNKT	1002, 1003, 1004, 1005, 1008, 1010, 1043, 1049, 1110, 1114, 1117, 1212, 1246, 1262	CONTIN;FR	1095,1225
BLAUSONIC	1045	CREA	1375,1384, 1385
BLUE STAR	1161	COSMEL	1106,1176
BLUESKY	1095,1098,1317	COSMOS	1059, 1095, 1106, 1284
BOTECH	1074, 1079, 1090	CPREMIER	1083,1379,
BRENDSTAR	1106	CROSELEY	1007,1019,1022, 1032, 1038, 1200, 1181
BRIONVEGA	1095,1096, 1022, 1024, 1025, 1033, 1041, 1042, 1148, 1163, 1164, 1251, 1223, 1305	CROWN	1095,1099,1007, 1019, 1106, 1118, 1133, 1134, 1168, 1208, 1213, 1231
BRITANNIA	1095,1045, 1159	CRYSTAL	1095
BROTHER	1133,1218,1294	CS ELECTR	1118
BRUNS	1022, 1149, 1166, 1171, 1158	CTC CLATRONIC	1095, 1099, 1019, 1038, 1045, 1118, 1133, 1166, 1168, 1171, 1240
BSR	1152,1157,1245,1249,1257	CURTIS	1098
BUSH	1153,1160,1161,1213	CYMATIC	1043,1045, 1152, 1161
CAMPER	1152	DAEWOO	1435,1095, 1096, 1098, 1038, 1040, 1045, 1106, 1108, 1118, 1170, 1177, 1214, 1262, 1290, 1291
CAPSONIC	1095, 1133	DANSAI	1103, 1133
CARTEL	1058,1059,1068,1218,1344	DAWA	1095, 1098
CASIO	1095,1096	DEGRAAF	1153
CBM	1019	DECCA	1095,1097,1098, 1043, 1045, 1048, 1150, 1170
CENTURY	1022, 1038	DECKTRON	1078
CGE	1095,1098,1099,1019,1032, 1038,1106,1200,1118,1168, 1152,1160,1161,1165,1193, 1323	DENVER	1095, 1106
CGM	1095,1099,1106, 1133, 1208, 1213, 1231	DESMET	1095,1098,1043, 1106, 1161, 1165
CIE	1106,1108,1118,1257	DIAMOND	1106,1108
CIHAN	1095,1098, 1152, 1161	DIBOSS	13911095
CLARIVOX	1095,1098,1012, 1022, 1038, 1043, 1044, 1149, 1175, 1176, 1240	DIGILINE	1095
CLATRONIC	1240	DIXI	1106
COFADEL	1036,1137, 1143, 1147	DOMEOS	1095, 1288
COMPUTRON	1095,1098,1106,1134, 1162,1225	DOMOH	1095
CONCEPT	1177	DORIC	1012, 1181, 1323
CONCORDE	1106	DUAL	1094, 1095, 1098, 1000, 1006, 1038, 1045, 1106, 1151, 1154, 1158, 1160, 1161, 1203, 1245
CONDOR	1095, 1098, 1019, 1106, 1133, 1166, 1168, 1171, 1165, 1320	DUAL-TEC	1094, 1095, 1098, 1000, 1006, 1038, 1045, 1106, 1151, 1154, 1158, 1160, 1161, 1164, 1245 ,1262, 1287, 1288, 1307
CONIC	1103	DUMONT	1095,1098, 1006, 1016, 1019, 1020, 1021, 1022, 1110, 1166, 1168, 1171, 1181
CONRAD	1098		
CONTEC	1045,1049, 1106, 1133, 1257		

TV Markaları (TV Brands)	TV Kodları (TV Code)	TV Markaları (TV Brands)	TV Kodları (TV Code)
DUX	1095, 1098	FLINT	1095, 1177, 1310
D-VISION	1095	FORMENTI	1095, 1098, 1099, 1012, 1019, 1022, 1043, 1045, 1106, 1110, 1133, 1166, 1168, 1171, 1152, 1161, 1165, 1181, 1201, 1204, 1245
DYNAMIC	1106	FORTRESS	1022
DYNISTY	1095, 1108	FRABA	1095
EDANLINE	1095, 1182	FRONTECH	1095, 1038, 1040, 1045, 1103, 1106, 1153, 1161, 1245
EDISON	1344	FUJITEC	1095
ELBE	1001, 1043, 1044, 1045, 1049, 1143, 1148, 1161, 1163, 1164, 1181, 1191, 1193, 1267, 1310	FUJITSU	1081, 1095, 1000, 1021, 1045, 1103, 1118, 1166, 1171, 1157, 1164, 1255, 1256, 1281
ELECTRO TECH	1106	FUMEO	1157
ELEKTRONSKA	1043, 1161	FUNAI	1049, 1106, 1133, 1257
ELIN	1095, 1098, 1006, 1045, 1106, 1158, 1162	GALACTEX	1045, 1133
ELITE	1110, 1165, 1342	GALAXI	1095, 1016
ELMAN	1166, 1171, 1161, 1245	GALAXIS	1095, 1099, 1016, 1168
ELTA	1166, 1171, 1161, 1245	GALAXY	1099, 1002, 1016, 1019, 1045, 1166, 1168, 1171
EMERSON	1095, 1098, 1099, 1016, 1019, 1020, 1022, 1038, 1045, 1133, 1166, 1171, 1161, 1165	GALERIA	1106
ENGEL	1149, 1161	GBC	1095, 1098, 1038, 1049, 1106, 1108, 1118, 1134, 1170, 1179, 1161, 1181,
ETRON	1106, 1134, 1226	1213	
EUROCOM	1161	GE	1146
EUROLINE	1315	GEBER	1151, 1154, 1155
EUROMAN	1095, 1098, 1007, 1045	GEC	1030, 1043, 1045, 1049, 1170, 1151, 1152, 1153, 1181, 1258
EUROPHON	1038, 1043, 1045, 1166, 1171, 1174, 1161	GELESO	1038, 1043, 1106, 1108, 1118, 1179, 1161, 1181
EXPERT	1100, 1144, 1151	GENERAL STAR	1211
FAGOR	1161, 1215	GENERAL TECHNIC	1106
FALCON	1106	GIANT	1095, 1098, 1045, 1141, 1243
FENNER	1095, 1098, 1106, 1108	GITEM	1095, 1098, 1003, 1004, 1137, 1146, 1155, 1156
FIDELIS	1095, 1098, 1045, 1103, 1106	GM	1095, 1106, 1133
FILSAL	1045, 1106	GMG	1095, 1106, 1133, 1168
FINLANDIA	1152, 1153	GOLDFUNK	1231
FINLUX	1095, 1098, 1006, 1012, 1015, 1016, 1020, 1021, 1040, 1043, 1106, 1166, 1168, 1170, 1171, 1158, 1162, 1181, 1224, 1261, 1284	GOLDSTAR	1095, 1098, 1000, 1014, 1040, 1045, 1103, 1106, 1118, 1167, 1172, 1153, 1157, 1161, 1211, 1232, 1288, 1313, 1318
FIRST LINE	1095, 1096, 1098, 1012, 1038, 1044, 1045, 1106, 1108, 1170, 1151, 1154, 1155, 1158, 1160, 1161, 1163, 1165, 1278	GOODING	1225
FISHER	1099, 1006, 1022, 1045, 1049, 1101, 1102, 1105, 1149, 1151, 1154, 1181, 1182, 1192, 1307	GOODMANS	1095, 1096, 1098, 1045, 1049, 1106, 1108, 1118, 1134, 1146, 1161, 1236, 1231, 1262
FLDELITY	1035, 1038, 1045, 1103, 1118, 1132, 1134, 1146, 1151, 1154, 1159, 1161		

TV Markaları (TV Brands)	TV Kodları (TV Code)	TV Markaları (TV Brands)	TV Kodları (TV Code)
GORENJE	1095, 1099, 1007, 1153, 1154	HYPSON	1095, 1098, 1106, 1133
GPM	1106, 1118	HYUNDAI	1405, 1086, 1095, 1098, 1230, 1270, 1295
GRAETZ	1236, 1285, 1312, 1316	IBERVISAO	1151, 1154, 1161
GRUNBERG	1373	ICE	1118, 1133, 1134
GRANADA	1095, 1098, 1012, 1043, 1045, 1049, 1117, 1125, 1141, 1152, 1153, 1159, 1181, 1185, 1194, 1204, 1243, 1264	IEG	1045
GRANDIN	1095, 1144, 1151, 1161, 1165, 1181, 1310	IHLAS	1095, 1208, 1236, 1273
GREAT WALL	1133, 1176, 1177	IMPER	1095, 1096, 1098, 1106, 1118, 1133, 1218
GRENADIER	1095, 1106, 1161, 1211	IMPERIAL	1095, 1098, 1099, 1019, 1032, 1038, 1200, 1133, 1168, 1152, 1160, 1161, 1193
GRONIC	1095, 1098, 1045, 1106, 1149, 1166, 1171, 1161	INDESIT	1139
GRUNDIG	1427, 1446, 1443, 1446, 1095, 1096, 1098, 1002, 1003, 1004, 1005, 1008, 1012, 1017, 1106, 1165, 1225, 1260, 1262, 1306	INF. REM. CONTR	1224
GTT	1095, 1106, 1168, 1213	INNOHIT	1095, 1098, 1014, 1038, 1043, 1045, 1103, 1106, 1118, 1134, 1170, 1181, 1213
HAMERSTEIN	1045, 1107, 1133, 1135	INTERBUY	1040
HAMPTON	1045, 1181	INTERDISCOUNT	1095, 1046, 1137, 1146
HANIMEX	1118	INTERFUNK	1094, 1095, 1098, 1014, 1025, 1038, 1043, 1045, 1103, 1106, 1114, 1118, 1125, 1134, 1137, 1168, 1170, 1151, 1154, 1155, 1158, 1181
HANSEATIC	1094, 1095, 1003, 1004, 1043, 1045, 1049, 1106, 1151, 1153, 1154, 1158, 1165, 1181, 1257, 1261, 1291, 1313	INTERVISION	1095, 1038, 1040, 1045, 1166, 1171, 1172, 1173, 1161
HANTAREX	1095, 1043, 1106	INTUM	1363
HARWARD	1403	IRRADIO	1095, 1098, 1012, 1014, 1040, 1103, 1106, 1118, 1133, 1134, 1161, 1231, 1262
HCM	1045, 1106, 1121, 1161, 1213	ISKRA	1043, 1045, 1166, 1171, 1161, 1208
HEMMERMANN	1045, 1145, 1166, 1171, 1151, 1154	ITC	1045, 1161
HEXA	1175, 1161	ITL	1095, 1106
HIGASHI	1045	ITT SCHAUB LORENZ	1095, 1098, 1106, 1151, 1154, 1161, 1181, 1205, 1236, 1284
HILINE	1106, 1133, 1134	ITT	1094, 1095, 1098, 1099, 1100, 1006, 1020, 1106, 1108, 1118, 1140, 1144, 1168, 1178, 1151, 1152, 1153, 1154, 1155, 1156, 1158, 1159, 1161, 1162, 1163, 1181, 1182, 1192, 1213, 123 6, 1241, 1224, 1231, 1255, 1261, 1284, 1285, 1312, 1316
HINARI	1095, 1048, 1103, 1106	JAMESON	1424
HISENSE	1394, 1153, 1182	JET POINT	1095, 1135
HISONIC	1105	JINLIPIU	1106
HITACHI	1096, 1045, 1049, 1103, 1138, 1143, 1167, 1151, 1152, 1153, 1154, 1161, 1162, 1181, 1188, 1189, 1190, 1244, 1220, 1258, 1259, 1261, 1262, 1291, 1308, 1323, 1333, 1340	JOHNSON	1045
HOSHAI	1213	JVC	1050, 1076, 1092, 1025, 1049,
HOTELTV	1341, 1361		
HUNTER	1274		
HYPER	1095, 1040, 1045, 1106, 1109, 1118, 1134, 1152, 1161, 1213, 1244		

TV Markaları (TV Brands)	TV Kodları (TV Code)	TV Markaları (TV Brands)	TV Kodları (TV Code)
	1132, 1134, 1135, 1227, 1228, 1262, 1292	LENOIR	1095,1098,1045,1106,1108, 1151,1154,1213
KAISER	1095	LEYCO	1095,1133,1170,1245,1257
KAISUI	1095,1045,1106,1118,1168, 1177,1213,1284,1310	LG	1395,1372,1429,1088,1288, 1304,1313,1318,1372
KAMAR	1105	LIESENKOTTER	1095,1110
KAMBROOK	1095,1045,1133,1138,1172	LIFE	1106
KAMOSONIC	1045	LIFETEC	1098
KAPSCH	1100,1006,1181,1255	LLOYD' S	1012,1045,1106,1133,1181
KARCHER	1095,1098,1099,1021,1044, 1045,1106,1174,152,1153, 213	LOEWE	1051,1151
KARDON	1255,1256,1281	LOEWE OPTA	1094, 1095, 1097, 1006, 1022, 1024, 1025, 1043, 1045
KAUASONIC	1274	LOGIK	1037,1048, 1132
KELVINATOR	1167	LUMA	1098,1116, 1179, 1157, 1164, 1255, 1342
KENDO	1095, 1098, 1000, 1038, 1045, 1106, 1148, 1166, 1171, 1179, 1157, 1163, 1164, 1181, 1193, 1255,1256,1281	LUMATRON	1095,1098
KENNDY	1098, 1000, 1038, 1137, 1148, 1157, 1164, 1181, 1193, 1255, 1256, 1281	LUXOR	1014, 1040, 1045, 1167, 1152, 1153, 1156, 1158, 1162, 1181, 1182, 1221, 1284
KENNEX	1095,1098,1231	M.ELECTRONIC	1094, 1095, 1098, 1006, 1008, 1014, 1016, 1020, 1021, 1022, 1038, 1040, 1043, 1106, 1108 , 1115, 1148, 1166, 1168, 1171, 1179, 1151, 1154, 1161, 1162, 1181, 1261, 1262, 1288, 130 7, 1313, 1315
KERION	1095,1098	MAAZ	1122, 1123, 1125
KIC	1045	MACTH-TALIA	1095
KIOTA	1133	MAGNADYNE	1095, 1098, 1002, 1022, 1038, 1043, 1106, 1166, 1168, 1171, 1179, 1151, 1154, 1161, 1181
KITT	1045, 1133	MAGNAFON	1095, 1012, 1016, 1043, 1045, 1166, 1171, 1181
KIYOGIN	1095	MAGNASONIC	1095,1098
KLARMAX	1043,1044,1045,1122,1123, 1125, 1152, 1161	MAGNEX	1095
KNEISSEL	1095,1001,1045,1193,1232, 1262,1310	MANESTH	1095,1152, 1155, 1158, 1161, 1165, 1185
KOBIC	1106	MANHATTAN	1231
KOENIG	1165,1181	MARANTZ	1095,1098
KOERTING	1095,1099,1022, 1030, 1151, 1154, 1165	MARECH	1165
KOLSTER	1095,1098,1038,1040,1044, 1045,1166,1171,1161	MARK	1208
KONIG	1012, 1161	MARKOT	1038
KONKA	1064,1067,1269,1272,1382	MATCHITALIA	1095,1106
KONTAKT	1225	MATSUI	1095, 1022, 1045, 1048, 1106, 1133, 1151, 1152, 1153, 1154, 1161, 1181, 1183, 1245, 1249,1225, 1253, 1278
KOTRON	1133	MATSUMA	1045, 1133, 1249
KRONNE	1045, 1161		
KUBAELETRONIC	1307		
KYOTO	1055,1043, 1045, 1161		
LAVIS	1043		
LEADER	1106,1300		
LEGEND	1095,1098,1045,1106,1133, 1176		
LENCO	1095,1098,1108, 1166, 1171, 1158, 1231		

TV Markaları (TV Brands)	TV Kodları (TV Code)	TV Markaları (TV Brands)	TV Kodları (TV Code)
MAXAM	1045, 1106, 1133	NIKKAI	1045, 1103, 1133, 1167
MAXELL	1106	NIKKO	1095, 1098, 1176
MAXWELL	1095, 1043, 1123, 1125, 1166, 1171	NIPPON	1339
MCE	1106	NOBLEX	1049, 1101, 1102, 1105, 1106, 1107, 1108
MEDION	1321	NOBLIKO	1012, 1016, 1019, 1038, 1045, 1166, 1171
MEGA	1095, 1096	NOC	1439
MEMPHIS	1176	NOKIA	1094, 1095, 1098, 1099, 1100, 1006, 1020, 1106, 1108, 1118, 1168, 1178, 1151, 1152, 1153, 1154, 1155, 1158, 1159, 1161, 1162, 1163, 1181, 1182, 1192, 1213, 1236, 1241, 1224, 1255, 1261, 1284, 1285, 1312, 1316
MERCURY	1045, 1106, 1133, 1204	NORDMENDE	1023, 1035, 1036, 1137, 1138, 1143, 1146, 1146, 1180, 1181, 1250, 1312
METZ	1098, 1002, 1003, 1004, 1008, 1009, 1010, 1025, 1028, 1029, 1231, 1235, 1319	NORDWAY	1160
MGA	1094, 1108, 1118, 1133	NORTEK	1095, 1262
MICRON	1045	NOVATRONIC	1095, 1106, 1108, 1133
MINERVA	1002, 1003, 1004, 1008, 1012, 1115, 1225	O GENERAL	1049, 1106
MITRONIC	1103	OCEANIC	1140, 1144, 1178, 1151, 1152, 1153, 1155, 1156, 1158, 1162, 1181, 1182, 1261
MITSUBISHI	1094, 1002, 1022, 1025, 1048, 1049, 1106, 1108, 1141, 1243, 1247, 1262	OKAL	1045
MIVAR	1001, 1011, 1013, 1014, 1039, 1043, 1045, 1207	OKANO	1099
MTC	1099, 1161	OLIMPIA	1059, 1344
MULTITECH	1094, 1095, 1099, 1038, 1040, 1043, 1045, 1048, 1049, 1106, 1118, 1121, 1133, 1166, 1171, 1161, 1213, 1236	OLUFSEN	1095, 1098, 1022
MURPHY	1012, 1045, 1152, 1160, 1161, 1181	OLYMPIC	1106
NAGEL	1031	ONCEAS	1038, 1045, 1106
NAGOTA	1152	ONIDA	1098
NAKASHI	1095	ONWA	1133, 1134, 1168, 1284
NAMSONIC	1106	ONWASAKY	1095, 1099, 1007, 1019, 1106, 1118, 1133, 1134, 1168, 1208, 1213, 1231
NAMSUNC	1106	ORAVASLOV	1095, 1022, 1161
NARITA	1108	ORAVA	1095, 1106
NEC	1044, 1048, 1049, 1106, 1108, 1177, 1212	ORIENT	1059, 1068, 1095, 1106, 1236, 1344
NECKERMANN	1095, 1096, 1098, 1099, 1003, 1004, 1008, 1025, 1045, 1046, 1047, 1110, 1114, 1148, 1179, 1152, 1153, 1165, 1232, 1257, 1262, 1315	ORION	1095, 1096, 1048, 1103, 1106, 1107, 1133, 1145, 1178, 1151, 1152, 1154, 1186, 1187, 1190, 1199, 1245, 1249, 1232, 1253, 1257, 1321
NECSTAR	1274	ORIONHUNGARY	1095, 1098, 1132
NEI	1095, 1098, 1176, 1152, 1161	ORMOND	1095, 1043, 1231
NEWMAR	1045, 1152, 1161	OR-ON	1213
NEWTECH	1095, 1045, 1279		
NEXT	1074, 1079, 1090, 1323, 1338, 1386		
NEXTICD	1338		

TV Markaları (TV Brands)	TV Kodları (TV Code)	TV Markaları (TV Brands)	TV Kodları (TV Code)
ORSOWE	1095,1098,1043,1133	PRANDONIPRINCE	1012,1038,1043, 1166,1171, 1179, 1152, 1181
OSAKI	1095,1098,1133, 1173	PREMIER	1415,1367,1063,1069, 1093, 1095, 1096, 1210, 1218, 1268, 1274, 1300, 1346, 1347, 1360,1379
OTHERLINE	1098,1043	PRIMA	1103, 1106
OTF	1095,1106	PRINCESS	1019,1106, 1110, 1158
OTTOVERSAND	1094,1095,1096,1097,1098, 1002,1003,1004,1008,1040, 1045,1046,1047,1049,1106, 1117,1146,1152,1153,1154, 1158, 1165, 1181, 1208, 1307	PROFILO	1428,1095, 1098, 1043, 1146, 1161, 1232, 1278
PAEL	1012,1045	PROLINE	1186
PALLADIUM	1099,1025,1148	PROSONIC	1095
PALSONIC	1095,1098,1045, 1103, 1118, 1133	PROTECH	1095,1098,1106,1168,1161, 1186, 1208, 1231, 1315
PANAMA	1095, 1098, 1038, 1133	PYE	1095, 1096, 1098, 1108, 1125
PANASHIBA	1106	QUALCRAFT	1012,1103,1118, 1166, 1171, 1245
PANASONIC	1052, 1053, 1085, 1003, 1004, 1117, 1161, 1811, 1242, 1246, 1229, 1280, 1356	QUASAR	1012, 1103, 1166, 1171, 1181, 1245
PANAVOX	1095, 1106, 1181	QUELLE	1094, 1095, 1098, 1002, 1006, 1012, 1014, 1015, 1016, 1020, 1021, 1040, 1045, 1046, 1048, 1102,1103, 1110, 1200, 1114, 1133, 1151, 1154, 1158
PANAVSION	1133	RADIOLA	1095,1096, 1098, 1116, 1125
PANORAMA	1045, 1106, 1118	RADIONETTE	1006, 1021, 1151, 1181
PANORAMIC	1137	RADIOTONE	1208,1240
PATHE CINEMA	1099, 1043, 1044, 1045, 1175, 1161, 1165	RANK	1012, 1153, 1160, 1181, 1196
PAUSA	1106	RBM	1012, 1153, 1160, 1181, 1198
PCM	1095, 1098	RECOR	1094,1095, 1098, 1133
PERSHIN	1012, 1175	REDIFFUSION	1158, 1181
PHILARMONIC	1045	REFLEX	1095, 1098, 1231
PHILCO	1095,1098, 1099, 1019, 1022, 1032, 1038, 1044, 1049, 1106, 1200, 1168, 1151, 1152, 1154, 1160,1181, 1193	REGAL	1406,1409,1095, 1098, 1345
PHILIPS	1444,1061, 1095, 1098, 1003, 1004, 1022, 1025, 1124, 1125, 1126, 1138, 1168, 1196, 1197, 1217, 1219, 1234, 1262, 1288, 1293, 1307, 1314, 1315, 1331	REGENTE	1106
PHOENIX	1201,1204	RFT	1022, 1208
PHONOLA	1196,1197	RITAR	1162
PILOT	1289,1312	RIZ	1161
PIONEER	1077,1091,1095, 1098, 1138, 1158, 1232, 1298, 1348	RM	1231
PLANTRON	1038,1043, 1106, 1179, 1152, 1181	RM2000	1095, 1098
PORTLAND	1095	ROADSTAR	1095,1098,1103, 1106, 1118, 1213, 1231, 1232, 1233, 1320
		ROBELECTR	1022, 1149
		ROWA	1045, 1106, 1133

TV Markaları (TV Brands)	TV Kodları (TV Code)	TV Markaları (TV Brands)	TV Kodları (TV Code)
ROWIDO	1012,1161	SCOTT	1095,1165
ROWSONIC	1045	SEG	1406,1409,1060,1095,1075, 1087,1098,1093,1019,1038, 1045,1166, 1171, 1161, 1231, 1345
ROYAL	1098,1045, 1106, 1118, 1133, 1168	SELECO	1095,1096,1098,1100,1000, 1040,1049,1146,1148,1179, 1180,1157,1161,1163,1164, 1193,1255,1256, 1281, 1342, 1343
RTF	1022	SEIKON	1436,1405,1300,1365, 1367, 1371, 1376,1382,1387, 1381,1392,1412
SABA	1433,1428,1072, 1095, 1098, 1025, 1026, 1035, 1036, 1043, 1106, 1108, 1137, 1138, 1141, 1143, 1146, 1152, 1155, 1161, 1181, 1237, 1240, 1250, 1232, 1254, 1278,1286	SEMP	1195
SAGEM	1310	SENDAY	1095
SAISHO	1044, 1045, 1047, 1108, 1118, 1185, 1245, 1249	SENTRA	1185,1204
SAKURA	1106	SENTIO	1381,1388
SALORA	1095,1020,1167,1179,1152, 1153, 1155, 1158, 1159, 1162, 1182, 1224	SEPHIA	1414
SAMBERS	1012,1014,1016,1019,1043, 1044,1166,1171,1205	SET	1095, 1161
SAMSUNG	1408,1430,1330,1082,109 5,1096,1098, 1099, 1014, 1025, 1045, 1048, 1103, 1105, 1106, 1107, 1135, 1170, 1173,1210,1217,1245, 1258,1262,1263,1311,1314,	SHARP	1413,1419,1087, 1049, 1119, 1120, 1121, 1132, 1204
SANDRACOLOR	1043,1045	SHIVAKI	1095, 1096
SANG	1095,1236,1316	SHOV	1407,1062, 1063, 1095, 1096, 1098, 1106,1279,1284
SANSUI	1433,1426,1065,1066,1095, 1096, 1098, 1002, 1019, 1045, 1103, 1106, 1108, 1117, 1118, 1134, 1138, 168,1170,1177,1158, 1160, 1161, 1162, 1192, 1195, 1233, 1261, 1264	SIAREM	1022, 1043, 1166, 1171, 1181
SANYO	1418,1433,1099,1006,1022, 1045, 1048, 1049, 1106, 1149, 1170, 1181, 1182, 1192, 1194, 1202, 1244, 1264,3299	SICATEL	1044, 1161
SAR	1095,1045, 1161	SICE	1002
SCHAUPLORENZ	1391,1432,1059,1068,109 5,1099,1106,1108, 1113, 1151, 1158, 1162, 1181, 1182, 1213, 1236, 1344	SIDEC	1161
SCHNEDER	1095,1096,1098,1000,1018, 1040, 1045, 1106, 1116, 1118, 1125, 1134, 1151, 1152, 1153, 1154, 1160, 1164, 1181, 1232, 1262,1287	SIEL	1019
		SIEMENS	1428,1095,1098,1002,100 3,1004,1005,1008, 1012, 1043, 1102, 1103, 1110, 1114, 1242, 1264
		SILMA	1095
		SILVA	1106
		SILVER	1118,1133
		SIMTEL	1095,1118,1133,1213,1307
		SINGER	1095,1098,1022, 1038, 1043, 1106, 1134, 1166, 1171, 1181, 1193, 1245
		SIERRA	1373, 1388, 1389,1381
		SINUDYNE	1095, 1096, 1022, 1118, 1145, 1166, 1171, 1151, 1154, 1164, 1181, 1186, 1187, 1199, 1245, 1227,1232, 1257, 1321
		SKAY	1213
		SLAVA	1045

TV Markaları (TV Brands)	TV Kodları (TV Code)	TV Markaları (TV Brands)	TV Kodları (TV Code)
SOLAVOX	1167, 1151, 1159, 1162	TASHIKO	1045, 1153, 1258, 1264
SONITRON	1022, 1045	TATUNG	1097, 1002, 1043, 1045, 1048, 1150, 1170
SONOKO	1095, 1098, 1045, 1106, 1133, 1213	TCL	1294
SONTEC	1095, 1099, 1040	TEAK	1094, 1095, 1098, 1045, 1106
SONY	1425, 1046, 1047, 1048, 1049, 1138, 1206, 1303, 1332	TEC	1095, 1000, 1038, 1045, 1106, 1160, 1161, 1245, 1288
SOUND MASTER	1106	TECHLINE	1095
SOUND COLOR	1095, 1098	TECHNICA	1118
SOUTHERNCROSS	1040	TECHNICS	1054, 1117, 1246
SOWTECH	1094, 1040	TECHNISAT	1095, 1232
SPECTRA	1095, 1218, 1282, 1283, 1294, 1299	TECHNOL	1094, 1045, 1106, 1108, 1133
STANDARD	1038, 1045, 1106, 1118, 1165	TECHWOOD	1075, 1087, 1089, 1095, 1096, 1098, 1099, 1019, 1038, 1104, 1132, 1153, 1160, 1
STAR	1098		161, 1231, 1275, 1315, 1345
STARLINE	1095	TEDELEX	1095, 1098, 1045, 1106, 1152, 1161
STARLITE	1106	TEINEL	1095, 1161
STARSUZIKA	1424	TEKNANT	1095, 1106
STARLUX	1106	TELE+	1095, 1106, 1209
STDNEY	1043	TELECHROM	1118, 1213
STERN	1100, 1000, 1137, 1148, 1179, 1157, 1163, 1164, 1255, 1342, 1343	TELEFAC	1106
STVII	1045, 1161	TELEFOX	1436, 1392, 1367, 1270, 1412
SUNKAI	1095, 1187, 1213	TELEFUNKEN	1428, 1095, 1037, 1038, 1043, 1106, 1107, 1108, 1200, 1137, 1138, 1139, 1141, 1142, 1146, 1147, 1161, 1240, 1248, 1232, 1262, 1278, 1286, 1323
SUNNY	1390, 1393, 1397, 1398, 1399, 1400, 1401, 1402, 1405, 1416, 1417, 1420, 1080, 1363, 1134, 1268, 1270, 1274, 1279, 1323, 1334, 1362, 1364, 1366, 1374, 1377, 1376, 1378, 1380, 1373	TELEOPTA	1106
SUNSTAR	1095	TELEPOINT	1095
SUNWATT	1095, 1098	TELESTAR	1095, 1106, 1133
SUPER	1084	TELETECH	1095, 1038
SUPERLA	1043, 1161	TELEVIDEON	1095, 1098, 1012, 1045, 1152, 1165, 1181
SUPERSONIC	1094, 1134, 1182, 1213	TELKOM	1095, 1161
SUPERTEC	1095, 1098, 1106, 1118	TELRA	1095, 1146, 1161
SUPRA	1095, 1105, 1106, 1108, 1211	TEMPEST	1045, 1106, 1118
SUPREME	1016	TENSAI	1095, 1098, 1006, 1021, 1038, 1045, 1103, 1106, 1108, 1118, 1166, 1171, 1172, 1174, 1161, 1165, 1231
SYCLINE	1106	TESLA	1044
TADISTAR	1168	TESLAALOV	1095, 1022, 1125, 1161
TALENT	1002	TETRAN	1161, 1165
TANDBERG	1009, 1015, 1024, 1025, 1029, 1043, 1137, 1143, 1164		
TANDY	1144, 1152, 1153		

TV Markaları (TV Brands)	TV Kodları (TV Code)	TV Markaları (TV Brands)	TV Kodları (TV Code)
THOMSON	1089, 1095, 1012, 1022, 1035, 1036, 1115, 1125, 1136, 1137, 1138, 1143, 1146, 1147, 1152, 1161, 1252, 1222, 1225, 1254, 1276, 1286	UNIVERSUM	1094, 1095, 1098, 1002, 1003, 1004, 1006, 1007, 1012, 1014, 1015, 1016, 1020, 1021, 1040, 1045, 1046, 1048, 1049, 1102, 1103, 1106, 1110, 1200, 1114, 1133, 1151, 1154, 1155, 1158, 1161, 1162, 1264, 1323
THORN	1185, 1224	UNIVOX	1095, 1098, 1022, 1038, 1044, 1151, 1161
THORNFERGUSON	1094, 1095, 1096, 1098, 1002, 1003, 1004, 1006, 1012, 1019, 1020, 1021, 1037, 1043, 1044, 1045, 1046, 1047, 1049, 1102, 1132, 1133, 1135, 1137, 1138, 1146, 1150, 1158, 1159, 1164, 1181, 1182, 1183, 1185, 1192, 1194, 1202, 1203, 1206, 1243, 1244, 1248, 1224, 1228, 1259, 1262, 1286, 1313	UNK	1095
TIBISHI	1045, 1106, 1118, 1133	URANYA	1095, 1012, 1043, 1106, 1108, 1166, 1171, 1165
TOBO	1106	UTAX	1045, 1106
TOKAI	1095, 1098, 1106, 1133	VANGUARD	1045, 1106, 1153
TOKYO	1213	VECO	1095, 1098, 1106
TOMITA	1045	VESTEL	1406, 1409, 1423, 1438, 1075, 1087, 1089, 1095, 1096, 1098, 1099, 1019, 1038, 1104, 1132, 1153, 1160, 1161, 1231, 1275, 1315, 1345
TOPVISION	1095, 1152, 1161, 1208	VEXA	1095, 1096, 1045, 1106, 1118, 1153, 1213
TOSHIBA	1060, 1094, 1045, 1049, 1183, 1184, 1185, 1193, 1195	VICEROY	1045, 1103, 1133
TR. CONTINENTS	1095, 1043, 1179	VIDEOCON	1098
TRANSONIC	1095, 1098, 1133, 1168	VIDEOLGIC	1045, 1118
TREVI	1106, 1118, 1213	VIDEOMAC	1045, 1133
TRIAD	1095, 1098, 1044	VIDEOTON	1095, 1040, 1043, 1045, 1168, 1178, 1152, 1153, 1160, 1161, 1221
TRIDENT	1056, 1057, 1070, 1095, 1274, 1300, 1349, 1358	VIDIKRON	1165
TRILUX	1095, 1208	VIDION	1106
TRISTAR	1132	VISA	1012, 1179, 1319
TRIUMPH	1016, 1245	VISAELECT	1019, 1045, 1161
TRIMAX	1381	VISION2001	1095
TRIVISION	1106	VISION2002	1106
TTR	1098, 1100	VISIOREX	1043
TV STAR	1152	VISTAR	1155, 1162
TVD	1098, 1255	VOXSON	1012, 1022, 1166, 1171, 1179
UHER	1098, 1100, 1018, 1152, 1165, 1255, 1307	WALKIE	1000
ULTRAVISION	1035, 1044	WALTHAM	1038, 1152, 1161
ULTRAVOX	1094, 1095, 1098, 1002, 1022, 1038, 1045, 1166, 1171, 1179, 1181, 1195, 1234	WATSON	1095, 1098, 1110, 1133, 1179, 1161, 1165, 1181, 1245, 1231
UNICRADIO	1099, 1043, 1045, 1158, 1161	WATT RADIO	1098, 1044, 1045, 1166, 1168, 1171, 1174, 1151, 1154, 1181, 1245, 1231
UNITED	1098, 1321	WEGA COLOR	1049
		WEGA VISION	1049
		WEGAVOX	1095, 1098, 1038, 1106, 1168, 1160, 1231

TV Markaları
(TV Brands)

TV Kodları
(TV Code)

TV Markaları
(TV Brands)

TV Kodları
(TV Code)

WELTBlick	1095, 1165
WESTON	1161
WHITE WESTING HOUSE	1094, 1095, 1099, 1100, 1016, 1019, 1045, 1106, 1148, 1166, 1168, 1161, 1165, 1255
WINERSAT	1106, 1213
WINSTON	1095, 1106, 1213
WINTERNITZ	1106, 1108, 1109, 1244
WORLD TECH	1095
YAMAHA	1357
YOKO	1095, 1045, 1106, 1133, 1137, 1152
YORK	1118
YUMATU	1095, 1106, 1133, 1168, 1238, 1296, 1300
ZAMPA	1180
ZIRWATEL	1106, 1286
OTHERS	1277

Uydu Markaları satellite Brands	Uydu Kodları satellite Code	Uydu Markaları satellite Brands	Uydu Kodları satellite Code
ABSYSS	3185		3132, 3187, 3188, 3258,
ACIKO	3408,3309,3484,3208, 3487,3235,3282,3055,3326, 3294,3488	BEON	3008
AIWA	3082	BESAT	3126
AKAI	3060,3208,3226,3487,3225, 3273,3278, 3293, 3301	BESTECH	3417,3371,3302,3312, 3294
AKIWA	3408,3420,3437,3484,3386, 3302,3309,3326	BESTTEL	3403,3432,3208,3487, 3302,3371
AMSTRAD	3416,3433,3434,3386,3089, 3309,3144,3185,3364,3233, 3215,3219,3314,3259	BIGALINE	3326,3302,3372
AMT	3326	BOFTEC	3186
ARCELIK	3406,3452,3043,3104,3116, 3165,3218,3266,3265,3286, 3297,3299, 3300	BOTECH	3428,3430,3388,3389,3392, 3309,3052,3386,3055,3341, 3372,3490,3065,3137,3139, 3183,3271,3272,3283,3296, 3325,3360,3131,3063,3053, 3366,3367,3320,3333,3375, 3379,3134
ARROX	3403,3450,3372,3302,3216, 3371,3272,3292	BRIGHT	1368,1380,3430,
ASAHI	3395,3261,3251,3282,3287, 3300, 3324, 3219	BRAVVO	3432,3094,3031,3115,3119, 3136,3144
ASIYASAT	3088,3019	CALIBER	3160,3254
AST	3108	CITYBOX	3317,3341,3386,3364
ASTRA/ASTRACOM	3389,3408,3302,3144,3326, 3265,3219,3312	CITIZEN	3208
ASTELINK	3091	CLARION	3212,3219
ASTON	3179	COMAG	3239
ATALANTA	3085	CONAX	3265,3251
ATLANTA	3423,3468,3395,3074,3480, 3455,3501,3478,3487,3003, 3205,3189,3208,3227,3302, 3308,3311, 3368	CONDOR	3169
AVERMEDIA	3424,3431,3292,3302,3282 3475,3326	CREA	3416,3444,3365,3259,3299
AXEN	3393,3469,3282	COSMOS	3469,3282
AVM	3418	COSHIP	3219, 3220
BAFF	3425,3444,3371,3282,3093, 3186,3228,3386,3229,3236, 3252, 3287, 3289, 3293, 3300, 3324, 3459	CVS	3403,3427,3436,3408,3418, 3498,3494,3395,3074,3484, 3227,3469,3217,3282,3302, 3326,3456,3364,3251,3215, 3371,3229,3436
BAFTEC	3415,3052,3166,3186,3320, 3302, 3066,3287	CTAGON	3411
BAUSAT	3237	DAUMLING	3029
BLACKBOX	3404	DAYSTAR	3260
BLACKTIGER	3400,3420,3372,3309	DAYTE	3096, 3001
BLUEBOX	3302	DECKTRON	3416,3444,3265
BEKO	3406,3452,3043,3104,337 1,3467,3116,3165, 3184, 3218, 3265, 3266, 3286, 3297, 3299,3224	DIGIBOX	3302,3212,3282
BENJAMIN	3418,3419,3432,3408,3083,3 018,3386,3021,3124, 3127,	DIGICAG	3131
		DIGIFUSION	3288
		DIGILINE	3403,3386,3309,3131, 3372,3229,3265,3252,3371, 3326,3302
		DIGIMASTER	3407,3063,3165,3337,3464
		DIGIPOLL	3364,3390,3326,3312,3309
		DIGISAT	3131
		DIGISTAR	3236
		DIGISTARBOX	3371
		DIGITAL-BOX	3252

UyduMarkaları satellite Brands	Uydu Kodları satellite Code	UyduMarkaları satellite Brands	Uydu Kodları satellite Code
DIGITURK	3245,3391,3444,3073, 3046, 3222, 3244, 3276, 3297, 3299,3232, 3265	GOLDMASTER	3491,3404,3407,3411,3412, 3416,3426,3428,3063, 3069,3385,3337,3130, 3131, 3165, 3184, 3185, 3176, 3212, 3235, 3259, 3243, 327 4,3361,3369,3374,3428, 3464,3481
DIGIX	3131	GOLDSMART	3408,3428
DIGINEXT	3219	GOLDSTAR	3464,3408,3428,3386
DIGLINK	3372	GOSHIP	3219
DIORA	3212	GRANDSON	3289,3300, 3324
DISCOVERY	3209,3228, 3213	GRUNDIG	3195,3309
DIXSTAR	3326	HARWARD	3233
DIVITONE	3231	HAUPPAUGE	3198
DRAGON	3055, 3067, 3183	HERZ	3408,3414,3415,3484,3386, 3326,3309,3233,3066, 3144,3230
DRAKE	3294	HEMCO	3131
DREAM BOX	3223, 3303	HIREMCO	3389,3432,3212,3382, 3322,3315, 3365,3470,
D-SMART	3224, 3241,3465 3250, 3269,3466,3281	HIRSCHMANN	3214
D-SAT	3427,3326	HOMETECH	3494,3363,3469,3282
DYNASAT	3260,3261,	HUMAX	3440,3140, 3178, 3199
ECHOSAT	3364,3144,3314,3282,3326	HWALIN	3100
ECHOSTAR	3009, 3023, 3149, 3190, 3263, 3298, 3144	HYUNDAI	3416,3417,3148, 3171, 3212, 3123, 3294, 3312, 3066, 3266
ELSA	3233	ID DIGITAL	3178, 3055
ELTON	3185	INPAX	3428,3223,3315, 3362, 3302,3458
EMME ESSE	3190	INTERMIL	3022
EROSAT	3099, 3282, 3326,	INTERSAT	3036,3112,3125, 3206
EUROGRAFF	3113	ITALTEL	3190
EUROSAT	3449,3099, 3282, 3326	INTUM	3469,3282
EUROWORLD	3302	ITT SCHAUBLORENZ	3204, 3205
EXPER	3097	ITT	3106, 3204, 3205
EXTREMEBOX	3384,3365,3326,3212	JBM	3408,3215,3428
FAIRMATE	3233	JIMEX	3280,3179
FINEPASS	3262,3278	JAMESON	3386,3395,3397,3418,3393, 3437,3309,3055,3302,3364, 3282,3372,
FINEST	3131,3212, 3320	KAWAI	3397,3443,3446,3448,3449, 3296,3326,3364
FOBEM	3364,3086,3117	KAMOSONIC	3403,3431,3386,3389,3320, 3302, 3131,3309,1371
FOCUS	3141,3213,3265,3144	KAON	3389,3131,3326
FORTEC STAR	3255,3453	KEITO	3403,3252,3371
FORLAND	3454	KODLU KUMANDA	3051,3052,3131
FRAU HOLLE	3029	KONKA	3233
FREEMAX	3469	KORAX	3389,3414,3427,3491,3481,
FREESKY	3364		
FULLY	3326,3302		
FUJISAT	3165,3215		
FUJITIME	3302		
FUJIYAMA	3260		
GAMMA	3123		
GECCO	3184		
GEIMA	3021		
GM	3085		
GMI	3085, 3003		
GLOBO	3371		
GOLD	3117		
GOLDENINTERSTAR	3265		

UyduMarkaları satellite Brands	Uydu Kodları satellite Code	UyduMarkaları satellite Brands	Uydu Kodları satellite Code
	3484,3477,3468,3326,3455, 3444,3427,3408,3401,3393, 3309,3302,3265,3397	NEWWAVE	3240
KVISION	3294	NEWLINE	3364
KING	3357	NEXTIME	3413,3062, 3252
KYOTO	3414,3052,3085, 3088, 3090, 3045, 3143, 3147, 3167, 3170, 3229, 3217, 3144	NEXT	3133,3384,3442,3365,3212, 3054,3461, 3098,3282,3110, 3200, 3113,3380,3164,3131, 3163,3183,3228,323,3249, 3281,3387,3409,3421,3310, 3313, 3358,3359,3370,3376, 3377,3367, 3289, 3322, 3327,3457,3460,3471
LASAT	3090, 3000, 3028	NEXTKEY	3415,3212,3219, 3251, 3066
LEADER	3239	NEXTPOWER	3133
LEGEND	3190	NEXTSTAR	3435,3212,3133,3131,3183, 3282,3169, 3228, 3240,3242, 3247, 3275, 3289, 3327, 3310,3326, 3365
LIFEMAX	3393,3476,3323	NEXTWAVE	3326,3064, 3109, 3123, 3159, 3227, 3229, 3256, 3240, 3242,3144
LINX	3422,3309,3326	NEOTIONBOX	3185
LINUX	3428	NOKIA	3106,3204, 3205, 3248
LOGIX	3131	NOVA	3013, 3146, 3152
LORENZENINC	3000, 3027, 3028, 3029, 3030, 3031, 3032, 3033, 3034, 3035	NOVATECH	3302,3309
LUXOR	3076	OLIMPIA	3130,3063
MAGIX	3265	OMEGA	3238
MAGNUM	3093,3024, 3025	ONBOARD-BOX	3403,3252,3371
MANHATTAN	3002,3024, 3025, 3026, 3130	ONWA	3131,3233, 3185
MEDIA COM	3260	OPENTEL	3213
MEDIALINK	3368	ORA	3131,3233
MEGA	3047,3174, 3238	ORIENT	3257,3265
MEGASAT	3386	PACE	3489,3015,3017,3039,3041, 3042,3046,3150,3156,3175, 3038
MICROSTAR	3415,3418,3427,3436,3469, 3395,3282,3251, 3302, 3066	PANASAT	3038
MILLENIUM	3282	PATRIOT	3155
MICROTIME	3469,3282	PEYSS	3414,3379,3061, 3217
MINIBOX	3302	PHILIPS	3073, 3046
MINISAT	3125,3172	PILOT	3004,3037, 3236
MINTON	3216	PIRANHA	3396,3326
MOONSTAR	3215, 3219, 3055,3183,3364	PIONEER	3050, 3095
MOTOSAT	3275	PIKO	3309
M-NET	3105	PLANET	3114,3120, 3234
MULTICHOICE	3017, 3040	PREMIER	3414,3425,3437,3440,344 1,3058,3087, 3093, 3142, 3143, 3211, 3230, 3237, 3215, 3259,3364,3166 3188,3221
MYSAT	3492,3357,3326	PROFILO	3188,3221
MEGASTAR	3235,3337	PROZEG	3277
MEWYORK	3097	POWERSAT	3411
MERSAT	3403,3418,3432,3371,3326, 3386,3469,3484,3448,3479, 3372,3494,3282,3202,3302	RADIX	3034
NETA	3451,3079,3080, 3012, 3014, 3154, 3264, 3246, 3295,5509		
NETEX	3312,3341,3219		
NETRON	3183		
NEWNEXT	3214		

Universal Remote Control For 8inl **V2**

Uydu Markaları satellite Brands	Uydu Kodları satellite Code	Uydu Markaları satellite Brands	Uydu Kodları satellite Code
RAMSAT	3408,3484,3364	SKYTECH	3408,3428,3429,3436,3448, 3394,3398,3399,
RC 2	3074		3333,3484,3341,3302,3383, 3219, 3240,3334,3312,3064, 3272,3446
REDLINE	3415,3427,3428,3429,3052, 3439,3462 3055, 3056, 3183, 3185, 3291, 3294, 3312, 3341, 3463, 3471	SKYMAX	3446
REGAL	3186	SHOV	3326
REX	3186	SMART	3384
ROADMASTER	3008, 3031,3112,3121,3128, 3131	SNX	3364
ROWELL	3484,3309,3326	SOFTLINE	3219
RSAT	3289	SONASHI	3208
RUBENIS	3216,3313	SONIX	3396,3275-3320
SABA	3405,3437,3372	SOUTHLINE	3364
SAGEM	3010	STAR DIJITAL	3010
SAKURA	3415,3144, 3233, 3213	STAR COM	3494,3410,3282,3252
SALURA	3011	STARSAT	3379,3395,3425,3444,3449, 3253, 3265, 3302,3326, 3317,3234
SAMSUNG	3074, 3168, 3227	STMBOX	3223
SAMUX	3418,3427,3428,3433,3475, 3053,3326,3312	STREAM	3190, 3052, 3183
SANGEAN	3092	STROM	3366,3052, 3138, 3183
SANSUI	3213,3069,3070,3251,3291, 3185	STRONG	3056, 3002, 3024, 3025, 3135, 3180
SATEX	3208,3487	SUNMOON	3017, 3040
SATELLITE	3003	SUNNY	3408,3418,3373,34443131,3 323,3031, 3103,3476,3114, 3116,3121,3053,3177,3285, 3363,3265,3373
SATARBOX	3212	SUPERMAX	3227, 3233, 3213, 3265, 3292
SATCOM	3213,3294	SUPERSON	3219
SATURK	3418,3393	SUPERSAT	
SEG	3192, 3193, 3203, 3245	SUPEX	3086, 3219
SEIKON	3265, 3055	TAKWANG	3020
SEOUL	3415,3432,3066, 3144, 3365, 3212, 3233, 3294, 3322	TANTEC	3268
SERVISAT	3008, 3192, 3193, 3203	TAPLIN	3390,3059,3326,3060,3071, 3208,3365,3212,3226,3277, 3278,3287,3293, 3300, 3301, 3324
SET	3005, 3016, 3048, 3049, 3101	TECHNOBOX	3371
SCHAUPLORENZ	3451,3204,3205, 3216, 3264	TECHNOMATE	3173
SETLUX	3145	TECHNOSAT	3405,3415,3472,3066,3147, 3488,3148,3212,3238,3267, 3314,3144, 3055
SHADOW	3233,3214	TECHSTAR	3428,3397,3136, 3210, 3321, 3265,3309,3326,3488
SHEEN	3282	TECHNOLINE	3363
SIEMENS	3221	TEKNIKSAT	3372,3309,3365
SIERRA	3397,3408,3302,3326,3484, 3488	TELEDUNYA	3378,3498,3295,3327,3264, 3254,3320,3365,3332
SILVERMAX	3418,3448,3326,3282	TELEFUNKEN	3188, 3236, 3221
SIMKO	3006		
SKY BOX	3223		
SKY TELEVISION	3078		
SKYLAB	3078		
S-LINE	3326,3484		
SABA	3372		
SKYMASTER	3214, 3285, 3185		

Uydu Markaları satellite Brands	Uydu Kodları satellite Code	Uydu Markaları satellite Brands	Uydu Kodları satellite Code
TELEMASTER	3024, 3025	X-MAX	3302
TELETEK	3236	XSAT	3107
TELEWIRE	3197	XTREME	3131, 3208
TELKOM	3122, 3186, 3192, 3193, 3203, 3063	YENICAG	3013, 3047, 3146, 3152
TELPAS	3395, 3212, 3302	YES	3181
TEMPO	3364, 3384, 3086, 3007, 3008, 3117, 3118, 3215	YONSAT	3114
TEON	3236	YUMATU	3403, 3413, 3437, 3371, 3055, 3074, 3386, 3097, 3027, 3031, 3227, 3229, 3252, 3313, 3309, 3459, 7162
TERMAL-AF	3063, 3074, 3081, 3097, 3003, 3008, 3009, 3102, 3130, 3186, 3227	ZAHAV	3194
TEVSAN	3364, 3326	ZEG	3236
TEVEL	3201	ZIRWATEL	3137
THOMSON	3075	ZODIAC	3191, 3196, 3182, 3202
TIVIBU	3402	OTHERS	3279, 3284,
TOCHIBO	3052, 3093, 3113		
TOFILD	3165, 3184, 3186		
TOKAI	3081, 3095		
TOPFIELD	3069, 3165, 3185, 3184		
TOSHIBA	3093, 3017		
TPS	3010		
TRIDENT	3427, 3474, 3053, 3480, 3219		
TRIMAX	3397, 3502, 3055, 3302, 3309, 3265, 3326, 3488		
TRISTAR	3302, 3326, 3309, 3292		
TRONIX	3265		
TWTNNR	3008		
UNICELL	3145		
VANTAGE	3413, 3057, 3072		
VESTEL	3445, 3068, 3384, 3122, 3131, 3151, 3153, 3154, 3186, 3232, 3222, 3244, 3245, 3270, 3297		
VOLTEL	3302		
VORTEC	3084		
VIVOX	3062		
VU+DUO	3358, 3359		
VU-ULTIMO	3495		
WANTED	3403		
WESTA	3326		
WESTSTAR	3259		
WISMANN	3410, 3474, 3419		
WIZTECH	3302, 3326, 3055		
WODEX	3212, 3277, 3365		
WORLDSAT	3107, 3157, 3158, 3161, 3162, 3163, 3215		
WORLDSTAR	3375		
WOON	3381, 3265, 3444		
XCOM	3107		
XCUISER	3148		
X. DREAM	3302		

Universal Remote Control For 8in1 **V2**

DVD Markaları DVD Brands	DVD Kodları DVD Code	DVD Markaları DVD Brands	DVD Kodları DVD Code
AFREEV	5029	ELTA	5073,5074
AIER PRINCE	5221, 5207	ELTAX	5125
AIWA	5053, 5000, 5123, 5282, 5379, 5380, 5381, 5382, 5383, 5384, 5471	EMERSON	5077
AKAI	5068, 5003, 5017, 5145, 5162, 5220	EVERESE	5141
AKIWA	5573,5574,5494,5434	FIRSTLINE	5508
AMOISONIC	5268,5269, 5270, 5310, 5361,5362,5323, 5324, 5325	FAV	5453,5591
AMSTRAN	5433	FISHER	5072
AMSTRAD	5022	FUJITEL	5488
APEX	5076	FUJIYAMA	5067, 5033
ARCELİK	5028,5030, 5142, 5147, 5154, 5188, 5189, 5487,5434	GOLDMASTER	5562,5564,5567,5502,5526, 5527, 5528, 5536, 5539, 5540, 5550, 5553,514
ASSAHI	5139	GOLDSTAR	5126,5136
AUDIOSONIC	5200	GOODMANS	5121
AVLIGHT	5222, 5209	GO-VIDIEO	5100,5004
AXEN	5575,5515,5502	GRUNDIG	5087,5117,5167, 5049, 5102, 5108
BBK	5230,5190, 5196, 5197, 5203, 5238, 5277, 5314, 5315, 5315, 5317, 5318, 5319,5429, 5430	HAIER	5218,5272, 5279
BEK	5189	HAOJI	5208
BEKO	5028, 5030, 5142, 5147, 5154, 5188, 5434, 5435, 5487	HOMETECH	5583,5530,5534, 5535, 5542, 5545, 5549, 5554, 5555, 5552,
BERTONE	5160, 5436, 5437	HARMONKARDON	5070,5018,5128
BLANTER	5265,5266	HISENSE	5215,5209,5309,5283
BRAWOO	5576	HITACHI	5083, 5001, 5009, 5010, 5120, 5127, 5130, 5131, 5056, 5366
BOSCHMANN	5143	HITER	5267
BOTECH	5441, 5507	HUABAO	5221, 5198, 5263, 5264
BOTS	5561	HUAJIA	5299
CAINI	5404	IDALL	5302, 5320, 5321, 5322, 5342, 5343, 5344, 5345, 5346
CHANG HONG	5311,5312, 5313, 5328, 5329	INTEGRA	5078
CLARION	5033	IRRADIO	5121,5133,5152
CVS	5562,5530,5161,5488,5501, 5522, 5532, 5538, 5542, 5545,5546, 5549	ITT SCHAUB LORENZ	5117,5121
CYBER HOME	5029	ITT	5117,5121
DAEWOO	5088,5011,5012,5124	JAMESON	5465
DELTA	5160	JBL	1095
DENON	5097,5098, 5014, 5114, 5124	JINGE	5402
DESAI	5195,5235, 5273	JINGEWANGPAI	5232, 5201, 5261, 5262, 5236
DIHE	5210,5237, 5244, 5403	JVC	5051, 5009, 5010, 5113, 5149, 5250, 5250, 5387, 5388, 5389, 5390, 5391
DINGTIAN	5301	JX2026G	5317
DIORA	5138, 5143	KAMOSONIC	5578,5530,5455,5456, 5457, 5466, 5518, 5530, 5531, 5535, 5541, 5554, 5549
DONGAN	5406	KARDON	5070
DONGDA	5400	KAWAI	5023,5137,5151, 5438, 5439, 5449, 5472, 5533
DVD	5044		
ELIT	5445, 5446, 5467, 5474, 5491		

Uydu Markaları satellite Brands	Uydu Kodları satellite Code	Uydu Markaları satellite Brands	Uydu Kodları satellite Code
KENWOOD	5069, 5114, 5134, 5135, 5227, 5385, 5386	OGATECH	5521
KETAI	5199	ONKYO	5032, 5037, 5249, 5375, 5376
KONKA	5089,5090, 5093, 5095	OPTIMUS	5002,5020
KYOTO	5212	ORIENT	5143,5445, 5446, 5467, 5474, 5491
LEADER	5530,5027,5031,5110,5440, 5518, 5522, 5530, 5544, 5551, 5556,	ORION	5135
LENCO	5042	OSAVA	5563
LG	5100,5168, 5222	OTHER DVD	5229, 5231, 5297, 5308, 5289, 5317, 5347, 5361, 5333,5396, 5405, 5407, 5410, 5411,5412,5413,5414, 5415, 5537
LINGSHUMA	5204, 5236	PANASONIC	5097, 5098, 5014, 5114, 5051, 5213, 5227, 5333, 5334, 5335, 5336,5337, 5338, 5339
LOEWE	5052,5087,5117,5167,5108	PLAYER	5548
LOEWE OPTA	5117	PANDA	5205,5255, 5256, 5257, 5424, 5425
LOWE	5087,5117,5167,5108	PEACOCK	5394
LUXMAN	5120	PENSONIC	5143,5445,5446,5467,5474
MAGNAVOX	5087, 5006	PHILIPS	5087, 5043, 5117, 5129, 5167, 5101, 5104, 5108, 5225, 5209, 5284, 5285, 5286, 5325,5331,5332,5447, 5448, 5559
MALATA	5216, 5218, 5223, 5227, 5192, 5193, 5250, 5234, 5280, 5290, 5291, 5292, 5293, 5294	PHISONEEP	5340
MANHATTAN	5121	PILIPPO	5587,5557,5138,5524
MARANTZ	5061,5006,5117,5129	PIONEER	5064, 5002, 5016, 5019, 5039, 5040, 5130, 5146, 5169, 5047, 5184, 5187, 5278,5278,5371,5372, 5373, 5374
MASCO	5506	PIRANHA	5494,5497, 5499, 5512
MASHILAN	5397	PLANET	5055,5445, 5464
MATSUI	5015,5167	PLAYSTATION	5026
MICO	5171,5172,5173,5174,5175, 5176,5177,5178, 5179, 5180	PREMIER	5586,5558,5058,5063,5151, 5449,5496, 5517, 5547
MOCROMAXX	5165,5167	PROFILO	5443
MINTON	5582,5593,5594,5595,5596, 5597,5600,5444,5473,5481, 5521	PROSCAN	5007
MISSON	5138	QINGHUATONGFANG	5257,5260
MITSUBISHI	5013	QISHIENG	5219,5356, 5357, 5358, 5359, 5360
MULTITECH	5524	RADIOSHACK	5084, 5008
MUSTEX	5080	RAITE	5041
NAD	5085,5116	RCA	5071
NAKAMICHI	5005, 5036	RED STAR	5475
NECVOX	5054	REGAL	5066, 5025
NEO	5445, 5446, 5463, 5467, 5474, 5491	REVOX	5117
NEXT	5563,5565,5581,5033,5441, 5442,5486, 5492, 5507, 5510	REVOXY	5042
NEXT DVD	5486	RMS	5357, 5407
NINTAUS	5217, 5211, 5239, 5240, 5241, 5242, 5303, 5304, 5305, 5353, 5354, 5355, 5111		
NIVA	5440		
NIWA	5141		
NOKIA	5117,5121		
NOWATECH	5302		
OBLIO	5569,5512		
OKON	5233		

DVD Markaları DVD Brands	DVD Kodları DVD Code	DVD Markaları DVD Brands	DVD Kodları DVD Code
ROADSTAR	5042, 5200,5119,5121,5048	SUPER JVC	5453
ROTEL	5113	SVA	5215,5245, 5423
ROWA	5343	TCL	5214,5228, 5206, 5258, 5259, 5330
SABA	5588,5133,5492,5511, 5543	TEAC	5118,5122,5130
SABRE	5059	TEACHLINE	5577
SAMPO	5086	TELEFUNKEN	5593,5600,5046
SAMSUNG	5075,5100, 5120, 5218, 5253, 5279, 5281, 5393	TECHSTAR	5567,5532
SANSUI	5226,5251, 5392	THIMSON	5243
SANYO	5072	THOMSON	5120,5166, 5045
SAST	5232,5261,5262, 5236, 5276, 5326, 5327	TIANLONG	5248,5398
SCHAUPLORENZ	5503	TOSHIBA	5059,5087,5096,5148,5186, 5247,5209,5367,5368, 5369,5370
SCARLET	5566	TREVIL	5200,5133
SEG	5066,5094, 5025, 5029, 5041	TRIDENT	5056, 5057, 5065, 5454, 5455, 5456, 5457, 5466, 5484, 5498, 7075, 5517
SEPIA	5524	TRIMAX	5566,5479,5480,5482, 5516, 5519, 5520, 5521, 5523, 5524, 5525, 5529,5546,
SEIKON	5551	TWOBOX	5050
SERTEC	5445	UNITED	5136
SHARP	5099, 5038, 5377, 5378	UNK	5165,5537
SHERWOOD	5021	VCD.MP3	5221
SHIDA	5274	VCD 2. 0	5468, 5469, 5470
SHINCO	5215,5245,5347,5348,5349, 5350,5351,5352,5478	VCD 3. 0	5468, 5469, 5470
SHOV	5033, 5118, 5140, 5182, 5446, 5450,5451,5452,5485	VESTEL	5560,5050,5066,5025,5034, 5121,5185,5458,5459,5493, 5500,5504,5555
SIERRA	5586,5463,5476, 5516, 5520, 5521, 5524, 5525, 5529, 5538,5533	VICTOM	5409
	5566,5482, 5479, 5480, 5516, 5519, 5520, 5521, 5523, 5524, 5525, 5529, 5546	VISIONIC	5587,5557
SIGA0B0	5427, 5428	VOCTOR	5250
SINUDYNE	5114,5134	VOXLINE	5060
SKYTECH	5571,5566,5480	WANYAN	5218,5300
SKYWORTH	5191, 5194, 5195, 5202, 5296	WATSON	5025
SKYWORTH VCD	5426	WE I FA	5254
SOFTLINE	5477	WHARFEDEALE	5082, 5495
SONY	5572,5079, 5026, 5035, 5112, 5115, 5150, 5153, 5159, 5164, 5170, 5109, 5246, 5352, 5340, 5341, 5363, 5364, 5365	WISMANN	5444
SOVA	5287	XENON	5524
STARCOM	5552,5549	XIANHUA	5395
SUBOR	5408	XINTIANLI	5306
SUNASK	5022	YAIM NETSTATION	5155,5156,5157
SUNNY	5570,5579,5580,5080,5 183,5526,5453, 5483, 5502, 5514,5515, 5545,5512	YAMAHA	5091, 5092, 5097, 5098, 5014, 5017, 5114, 5117, 5158
SUNSAI	5524	YINGZHIBAO	5405
		YITONG	5396
		YOUBISHENG	5298, 5307
		YUXING	5271,5288
		ZENITH	5075, 5081
		ZHAOWEI	5329

Uydu Markaları satellite Brands	Uydu Kodları satellite Code	Uydu Markaları satellite Brands	Uydu Kodları satellite Code
AIWA	7080, 7081, 7083, 7085, 5100	ORA	7089
AKAI	7024, 7033	ORIENT	7000, 7021, 7042, 7045
ARCELİK	7168, 7002, 7012, 7015, 7028, 7034, 7127	OSAWA	7146
ASA	7060, 7061	OPENBOX	
BEKO	7179, 7096, 7002, 7012, 7028, 7034, 7127	OTHERS	7080, 7083, 7085, 7111
BLAUPUNKT	7064	PANASONIC	7052, 7053, 7092, 7134
BOTS	7145, 7101, 7102, 7103	PHILCO	7065
CARTEL	7089	PHILIPS	7055, 7056, 7057, 7058
CGE	7065	PILIPPO	7094
CLARION	7089	PIONEER	7164, 7068, 7069, 7041, 7106, 7107, 7108
COMPACT	7077	PLOSTAR	7089
CONCRYPT	7077	PREMIER	7179, 7167, 7088, 7123, 7089, 7098, 7001, 7003, 7009, 7014, 7016, 7022, 7039, 7112, 7120, 7123, 7026, 7032, 7038
CPREMIER	7088	PROFILO	7172
CROSLEY	7063	ROADMASTER	7089, 7048
CVS	7171, 7089	ROADSTAR	7149, 7043
DAEWOO	7087	SABA	7073, 7172
DELTA	7089	SAMSUNG	7017
DIJITAL	7089	SANSUI	7147
DIORA	7116	SCHNEIDER	7031
DUMONT	7060, 7061	SELECO	7077
FILMNET	7077	SHARP	7070
FINLUX	7060, 7061	SHOV	7176, 7089, 7098, 7010, 7011, 7023, 7025, 7027, 7033, 7113, 7129, 7130
FLORA	7089	SIEMENS	7064
FUJITEC	7088, 7089	SKY TELEVISION	7076
FUJIYAMA	7122	SONIA	7089
GOLDMASTER	7178, 7151, 7153, 7154, 7157, 7158, 7159, 7160, 7148, 7165, 7141, 7136, 7137	SONY	7062, 7063, 7079, 7126
GOLDSTAR	7071	SOWTECH	7062
GRUNDIG	7059, 7046, 7047	STARSUZUKA	7161
HARMON KARDON	7118	STREAM	7044
HITACHI	7073	STREAM TELE+	7044
IMPERIAL	7065	SUNNY	7179, 7143, 7144, 7152, 7163, 7123, 7089, 7099, 7100, 7003, 7004, 7005, 7008, 7016, 7018, 7027, 7139
JVC	1050, 7054, 7006, 7007, 7019, 7030, 7104, 7105, 7109, 7123, 7133	SUPERSONY	7089
KAMASONIC	7089	TANDBERG	7073
KAWAI	7162, 7179, 7150, 7167, 7084, 7123, 7086, 7088, 7089, 7093, 7029	TEAC	7071
KENWOOD	7075, 7110, 7110, 7124	TECHNICS	7104, 7117, 7125
LEADER	7169, 7174, 7173, 7089, 7138, 7139, 7140	TECHNOVA	7095
LG	7096, 7036, 7037	TECHWOOD	7082
LIESENKOTTER	7064	TELE+	7077, 7044
LIFE	7064	TELEFUNKEN	7172, 7065, 7091, 7035
LOEWE	7051	T.TEC	7123
LUXOR	7056	THOMSON	7072, 7073
M. ELECTRONIC	7060, 7061	THORN FERGUSON	7055, 7056, 7057, 7058, 7062
MARANTZ	7055, 7114	UNIVERSUM	7060, 7061, 7064, 7065
MASTER	7090	VESTEL	7024, 7033, 7119, 7121, 7128, 7131, 7166,
MINTON	7178, 7089	VISIONIC	7179
MIKADO	7178, 7142, 7167, 7156	V-SONIC	7089
M-NET	7077, 7078	WESTA	7027
NECKERMANN	7064	WEST	7166
NECSTAR	7095	YAMAHA	7074, 7013
NEWGOLD	7089	YUMATU	7085
NIWA	7040, 7049, 7115		
NORDMENDE	7073		
ONKYO	7097, 7020		